

Model No.: 6016A10

Description: Plastic Series One Way Control Station with Integral Canopy with Push to Stop & Pull to release

**Mushroom Emergency Stop Trigger Pushbutton** 



#### Salient Features:

- Shrouded cover for Environmental protection
- Aesthetically elegant
- Robust Construction
- Simple to fix
- Safe operation
- · Good flame resistance
- Prevention against accidental actuation
- Long life
- Push to Off Pull to release function
- For elevator function

#### **General Characteristics:**

It consists of box yellow cover black case fitted with one push to OFF, pull to release Mushroom Emergency Stop Trigger Pushbutton (Model: P2AMPPT4) with cover mounting S... series contact elements. Top of actuator is permanently marked 'PULL TO RELEASE'. It is provided with a shroud to prevent accidental actuation & and also as an environmental protection.

**BOX:** The box is made of ABS or PC FR. It is composed of a case and a cover, joined together with self tapping screws. When with all switching components and cable installed, it assures protection class IP65 as per IEC 60529 & 4X,12 as per UL50. Box bottom wall has openings for PG13.5 cable gland. The box can be permanently marked with legend as requested on cover & is resistant to water, mild solvents and wear out. It has two holes for the fixation of the panel to a concrete wall, suitable for usage with two 4 mm diameter screws and 2 wall dowels, part of the pit box supply.

Box cover is stiff enough to prevent its breaking by the operating forces of the stop switch.

**CONNECTORS**: NA

**STOP SWITCH:** Refer Data Sheet for Ø22.5 Plastic series Emergency Stop Red Actuator, Push to Stop, Pull to Release with trigger with Marking (Model: P2AMPPT4)

### **ECOLOGICAL REQUIREMENT:**

Teknic ensures the fulfillment of the following ecological requirements

#### **Prohibited Substances:**

The product shall not contain any hazardous substances restricted by RoHS Directive 2011/65/EC.

### Substances to be avoided:

The use of hazardous substances is avoided: Chromium VI for metallic surface coatings, zinc layers and pigmented plastics

DS: QA: 51 Rev C

Page 1 of 8



Available types	ELINET C
	6017A10  Plastic Series One Way Control Station with Integral Canopy with Push to Stop & Turn to release Mushroom Stop actuator with P2AML4 6018A10  Plastic Series One Way Control Station with Integral Canopy Yellow Cover Black housing (only enclosure) Other types available on request. Cover & case colors available on request
Degree of protection	: IP65 as per IEC 60529 & 4X,12 as per UL50
Degree of Pollution	: 3
Applicable standards	UL508 IEC 60947-5-1 & 60947-5-5 CSA 22.2
Product Certification	( €

DS: QA: 51 Rev C Page 2 of 8




### **Mechanical Characteristics:**

Function indicator		: Other marking can be provided on request
Terminal Capacity of contact block		: Maximum 2X1.5mm² or 1X 2.5mm²
, ,		: Minimum 1X0.5mm²
Terminal marking on contact block		: 1NC 2 & 3NO 4
Terminal Torque on contact block	Nm	: 0.8 Screw head compatible with Posidrive or Phillips screwdriver
Contact material of contact block		: Brass terminal, silver rivet gold plated (Low Voltage application)
Operation of contact block		: Slow make/break
Operating torque	Nm	: 0.8
Operating force of Emergency Stop	N	: 14-20
Positive operation		: All functions incorporating an NC contact are positive opening
Conforming to IEC/EN 60947-5-1 Appendix K		operation
Operating travel	mm	: 5
Mechanical life		: Element: over 2 million operations
		: Mushroom Stop Actuator: 0.1 million operations
Ambient	°C	: -25 to +70
Storage	°C	: -25 to +40
Overall Dimensions with sketch (LXBXH)	mm	75
		25
		H H H
		8
API and the second of the second		01 P 11 (1 0 2 2 2 1 2 1 2 2 2 2 2 2 2 2 2 2 2 2
Vibration resistance	Hz	: Stop Pushbutton 8g acceleration; frequency 40-500Hz
Conforming to IEC 60068-2-6		Ohan Darkhattan O ahaala at 45m aarahan 14 44m a 44 140
Shock resistance		: Stop Pushbutton 3 shocks at 15g acceleration & 11ms; total 18
Conforming to IEC 60068-2-27	0	shocks.
Viewing Angle		: NA
Optical Axial intensity	mcd	: NA
Weight	gms	: 170

DS: QA: 51 Rev C Page 3 of 8




#### **Electrical Characteristics of contacts:**



#### Accessories & codes:

NA

### **Ordering codes**




DS: QA: 51 Rev C Page 4 of 8




### **Mounting Instructions:**

<u>Safety regulations:</u> This unit may be installed & commissioned by personnel who are familiar with current regulation for health & safety at work & accident prevention. Ensure local regulations are met especially those relating to safety. This is for use on flat surface of type 4X, 12 enclosure.



Ensure that this actuator will operate fully after installation. Failure to follow these will result in death or serious injury.



DS: QA: 51 Rev C

Page 5 of 8




#### To install:





Insert the actuator in the cover hole




Locate it with the knotch provided



Place the metal plate with pointed edges facing upwards



Insert the Lock ring




Turn the lock ring in a clockwise direction & tighten it with Spanner (P2SPNR) with a torque of 2Nm




Place the bracket on the holder



Press fit it to hear a click sound



Assemble the element to the bracket



Press it to assemble it



Place the cover on the housing




Tighten the screws with a torque of 0.8Nm.
Tighten all the screws with equal torque. Do not overtighten them as they would slip.

DS: QA: 51 Rev C Page 6 of 8



#### To uninstall:




Loosen the screws with a screw driver




Remove the cover



Remove the clip on element



Remove the lock ring by turning it anticlockwise



Remove the metal plate



Remove the actuator

#### To install:


With S... series cover mounting contact blocks




Insert the actuator in the cover hole



Locate it with the knotch provided




Place the metal plate with pointed edges facing upwards



Insert the Lock ring




Tighten it with a torque of 2Nm



Place the bracket with S... series elements on the holder



Press it till you hear a click



Place the cover on the housing



Tighten the screws with a torque of 0.8Nm.
Tighten all the screws with equal torque. Do not overtighten them as they would slip.

DS: QA: 51 Rev C Page 7 of 8



#### To uninstall:




Loosen the screws with a screwdriver




Remove the cover



Insert the Screwdriver in the bracket slot & twist it.
The bracket separates out



Turn the lock ring with a spanner in anticlockwise direction



Remove the lock ring by turning it anticlockwise



Remove the metal plate



Remove the actuator

If any more information is required, kindly contact our Marketing Department at +91-22-42532500 or email at <a href="mailto:ram.talreja@teknic.co.in">ram.talreja@teknic.co.in</a>

DS: QA: 51 Rev C

Page 8 of 8